
## PROBE MOUNTING



NOTES: THE TEMPERATURE SENSOR MOUNTING SHOULD BE IN A PLACE THAT IS FREE OF EXHAUST GASES OR COWL FLAPS AIRFLOW. THE IDEAL PLACE IS TWO FEET OUT FROM THE WING ROOT ON THE BOTTOM OF THE WING. SENSOR LEADS MAY BE LENGTHENED OR SHORTENED WITHOUT AFFECTING

CALIBRATION.

IF MOUNTED IN FIBERGLASS OR A NON GROUNDED STRUCTURE, SHIELD WIRE MUST BE TIED TO AIRFRAME ELECTRICAL GROUND

REVISIONS			AVTRONING			
NO.	DATE	BY	427 Hillcrest	Way Redw	ood C	ity, CA 94062
1	6/14/07	RGW	C3(	17DC	$\cap$	ITI TNIE
2	2/14/09	RGW	C307PS OUTLINE			
3			RGW	<sup>Date:</sup> 5/11/9	5	Drawing Number:
4			Approved by: DNT	Sheet:		303-017
5			Size:	Scale: NONE		000 017