



I recommend waiting to drill the holes until you have the acrylic panels cut and (carefully) using the acrylic panels as a pilot hole guide.

**Fancy Supporting the Project?**



[patreon.com/Captain\\_Bob](https://patreon.com/Captain_Bob)



[paypal.me/CaptainBobSimulation](https://paypal.me/CaptainBobSimulation)